

ez-Migration Trap II [BT1013]

MegaView Science Co., Ltd.

https://shop.bugdorm.com · https://megaview.com.tw



Package Contents

- x1 Fabric Trap Body [BT1013-0]
- x2 Shock-corded Poles [DM0065-10]
- x2 Collection Heads [BT0002] (pre-installed)
- x6 Collection |ars [DP0076-500] (x2 pre-installed)
- x10 Guy Lines [DC0905-3]
- x10 Plastic X-Stakes [DP0026]
- x8 Alloy Pin Stakes [DM0008]
- x1 Carrying Bag [DC0013]




Fig. A

NOTE: The X-Stakes hold firm in the loose ground, but they do not work well in rocky soil. Prepare proper stakes as needed to confront terrains specific to the site.

Set Up the Trap

- 1. Lay out the trap body with the white side up.
- 2. Assemble poles. Make sure the narrow end of each pole section is fully seated in the neighboring section.
- 3. Push spring pins at the corners of one side into the ends of one pole (Fig. A). Take care to maintain a gentle curve in the pole.
- 4. Clip the hooks on the trap around the pole to form a mesh panel.
- 5. Repeat Steps 3-4 with the other pole and the other side of the trap.
- 6. Guy out both mesh panels temporarily from the top of the poles to erect the trap. Each inverted Y-shaped collection head should sit over the top of each pole. Adjust the trap base and stake out necessary points to secure the trap on the ground.
- 7. Adjust the guy lines in Step 6 to erect the trap in a proper shape and tension.
- 8. Guy out the trap from guy points using X-stakes. See Fig. B an example of the trap setup.
- 9. Fasten ribbons around the trap collection head and collection jar to ensure the collection head stands up straight.
- 10. There is a "moth excluder" (16-cell grid, 1x1 cm per cell) plugged into the oblique pipe opening where insects enter the collection head. Push the moth excluder loose and pull it out from the opening if not needed.

Each trap component can be purchased and replaced individually in case of loss or damage. To replace the collection head or fabric trap body, please refer to the manual "Trap Collection Head" included in the package for detailed instructions.

